

QCOM Meters ¹				A/NZ GM National Standard Meters (Audit Screen and Hard Meters) ²	
Meter Name - Group 0 Meters	Meter ID ³	Meter ID	QCOM Meter Description	Meter Name	Meter Description [\$,] unless indicated otherwise
TOTAL EGM STROKE	0	0x00	(count of total games played, not including free spins or residual gamble) <i>Every play commencement</i>	GAMES PLAYED	total number of games played - [Play]
TOTAL EGM TURNOVER	1	0x01	(cents played) <i>Every play commencement & residual gamble</i>	TURNOVER	total value in dollars of bets made from the player's credit meter (note gamble bets such as double up are not bet from the player's credit meter)
TOTAL EGM WINS	2	0x02	added to credit meter (incl. wins paid directly from hopper) <i>Upon confirmed winnings (i.e. after double-up/gamble), residual gamble wins & other wins depending on the game)</i>	TOTAL WINS	total value in dollars of all prizes awarded to the player's credit meter (incl. Residual Credit Gamble prizes) [plus IGT variant of Download jackpot]
TOTAL EGM CANCEL CREDIT	3	0x03	(or hand pays, excl. ticket printer) <i>Upon exit from CC lockup & residual CC lockup</i>	CANCELLED CREDITS	total of all credits cancelled from the Credit meter by attendant and all credits paid from the Credit meter by ticket
TOTAL EGM CASH TICKET PRINTER OUT	4	0x04	<i>Not used in NZ</i>		
TOTAL EGM CENTS IN	5	0x05	(Coins/Tokens, Notes and Cashless In)	MONEY IN	total value in dollars of coins and or banknotes inserted to register credits on the player's credit meter together with transfers to the machine to register credits on the player's credit meter [Except for IGT variant, all Download Jackpot wins go to this meter – see also Cashless In]
TOTAL EGM CENTS OUT	6	0x06	(Coins/Tokens and Cashless Out. Not including Total EGM Cancelled Credit or Cash Ticket out)	MONEY OUT	total value in dollars of credits redeemed from the player's credit meter by hopper pay, ticket print, cancelled credit or account transfer, but not extra coin out errors or short pays
TOTAL EGM SAP WINS	7	0x07	<i>(including wins not added to credit meter) – not currently used in NZ</i>		
TOTAL EGM LP WINS	8	0x08	<i>Not used in NZ</i>		
	9- 12	0x09...0x0C	<i>Reserved (not used)</i>		
TOTAL EGM DOWNLOAD JACKPOT WINS ⁴	13	0x0D	<i>(E.g. Cashcade jackpot wins)</i>		
	14 - 15	0x1E & 0x0F	<i>Reserved (do not send)</i>		

¹ QCOM meters are applicable to a number of Australian jurisdictions. Functionality such as Cash Tickets and Cashless Out are not used in NZ Class 4 gambling. Cashless In is only used for Download Jackpots [except for IGT] such as Cashcade that transfer jackpot wins electronically to the gaming machine.

² Hard meters are not normally required in QCOM operation. However, New Zealand has retained hard meters in association with display of National Standard meters.

³ QCOM meter ID showing Decimal or Hex (0x..) are identifiers you may see on meters read via the Electronic Meter Access software installed on the venue PC.

⁴ Total EGM Download Jackpot Wins records all jackpots wins awarded direct to the gaming machine by a downloadable jackpot system e.g. Cashcade. Jackpot wins are treated as an electronic transfer of funds that also increments Total EGM cashless credit in meter. Electronic funds transfer will also increment Total EGM Cents In meter, which records all cash input into a gaming machine.

Meter Name - Group 1 Meters	Meter ID	Meter ID	QCOM Meter Description	Meter Name	Meter Description [\$.] unless indicated otherwise
TOTAL EGM HOPPER REFILLS	16	0x10	<i>Upon a refill being performed</i>	HOPPER REFILL	total of all hopper refills
TOTAL EGM COINS/TOKENS IN	17	0x11	(excl. refills)	COINS IN	total of all coins in but not hopper refills
TOTAL EGM COINS/TOKENS OUT	18	0x12	(i.e. hopper collects, excl. extra coins paid)	COINS OUT	total of all coins out from hopper, but not extra coins out or short pays
TOTAL EGM COINS/TOKENS TO CASH BOX	19	0x13	(i.e. in cents, excluding notes in)	CASH BOX	total of all coins deposited to the cash (drop) box
TOTAL EGM CASHLESS CREDIT IN	20	0x14	(Including all EGM download Jackpot wins) [Only used in Class 4 gambling for download of jackpot wins.]	CASHLESS IN	total of all credits electronically transferred to the gaming machine (if applicable), or paid to credit meter and not added to Total Wins [Except for IGT variant all Download Jackpot wins go to this meter – see also Money In]
<i>TOTAL EGM CASHLESS CREDIT OUT</i>	<i>21</i>	<i>0x15</i>	<i>(not including cashless out failed/cancelled) Not used in NZ</i>	<i>CASHLESS OUT</i>	<i>total of all credits electronically transferred from the gaming machine, if applicable</i>
TOTAL EGM NOTE ACCEPTOR CENTS IN	22	0x16		BANKNOTES IN	total of all banknotes accepted, if applicable.
TOTAL EGM NOTES IN	23	0x17	(count)		
TOTAL RESIDUAL CREDIT REMOVAL TURNOVER	24	0x18		RCR TURNOVER	residual credit removal turnover
TOTAL RESIDUAL CREDIT REMOVAL WINS	25	0x19		RCR WIN	residual credit removal wins
	<i>26 - 31</i>	<i>0x1A...0x1F</i>	<i>Reserved (not in use)</i>		
Meter Name - Group 2 Meters	Meter ID	Meter ID	QCOM Meter Description	Meter Name	Meter Description [\$.] unless indicated otherwise
TOTAL EGM \$5 NOTES IN	32	0x20	(count)		The National Standard requires that gaming machines fitted with banknote acceptors must maintain sufficient metering to be able to report –
TOTAL EGM \$10 NOTES IN	33	0x21	(count)		Total monetary value of banknotes accepted (Banknote Money In)
TOTAL EGM \$20 NOTES IN	34	0x22	(count)		Total number of banknotes accepted (Banknote Count)
TOTAL EGM \$50 NOTES IN	35	0x23	(count)		Counts of all rejected banknotes (Banknote Rejects)
TOTAL EGM \$100 NOTES IN	36	0x24	(count)		The number of banknotes accepted for each denomination, and
	<i>37 - 47</i>	<i>0x25...0x2F</i>	<i>Reserved (do not send)</i>		<i>The value of the last five banknotes accepted (with time stamps)</i>